PMD-200™

Pain Monitoring System

User Manual

© Copyright, 2023 Medasense Biometrics Ltd. All rights reserved.

This User Manual contains proprietary information of Medasense Biometrics Ltd. Any reproduction, adaptation (including translation, editing or any other change to the content), distribution or making available to the public by any means, without prior written permission from Medasense Biometrics Ltd. is strictly prohibited.

PMD-200 User Manual

Medasense Biometrics Ltd.
4 Hachilazon St.
Ramat Gan, Israel, 5252268
Tel: +972-73-7690321 | Fax: +972-3-5183878
Email: info@medasense.com
www.medasense.com

EC REP European Authorized Representative
CEpartner4U BV
Esdoornlaan 13 3951 DB Maarn, The Netherlands
Tel: +31 343 442.524 / Fax: +31 343 442 162
Mobile: +31 6 516 536.26
Email: office@CEpartner4U.com

CE 0344

CH REP Switzerland Authorized Representative
MedEnvoy Switzerland
Gotthardstrasse 28
6302 Zug
Switzerland

Disclaimer

Every care has been taken to ensure the accuracy of the information in this document. Medasense Biometrics Ltd. ("Medasense") assumes no liability for use of this document if any unauthorized changes to the content or format have been made. Medasense reserves the right to make changes to this User Manual and the product described herein without further notice.

To ensure proper use, handling and care of the products, purchaser should consult the product specific literature, instruction manual, and/or labeling included with the product or otherwise available.

Before using the PMD-200 system, users must read and fully understand all information and instructions provided with the product. For additional information and questions, please contact our customer support representative.

This User Manual is a reference tool for users of the PMD-200; it does not constitute medical advice. The PMD-200 monitor is not a substitute for your professional judgment. The licensed healthcare practitioner using the product is responsible in full for assessing each situation, based on his or her own experience and on the patient's condition.

Intended Audience

This manual provides information to health-care professionals acting as caregivers and technical support staff in a hospital or hospital-type setting for operation and maintenance of the monitoring system. Refer to the institution for any additional training or skill requirements beyond those identified here for operation and maintenance of the monitoring system. Before operating, thoroughly read this manual.

Table of Contents

1. Important Safety Information 1
Types of Notes 1
Warnings 2
Cautions 3
Equipment Classification 4
Equipment Symbols 5
2. Overview 7
Intended Use 7
Indications for Use 7
Contraindications and Limitations 7
Contraindicated Situations 7
Unevaluated Conditions 8
System Description and Operating Concept 8
Training 10
Screen Layout 10
3. System Components 12
Monitor 13
Front Panel 13
Back Panel 13
Side Panel 14
Software 15
Finger Probe 15
Single use Sensor 15
Power Cable 16
Power Requirements 16
Battery Backup 16
4. Installation and Setup 18
Selecting a Location 18
Connecting the System 19
Powering ON the PMD-200 20
5. Monitoring Mode 22

1. Connecting the Patient to the PMD-200 22
2. Starting the Monitoring Session 25
3. Stopping the Monitoring Session 29
6. Advanced Tools 31
Adding Patient Details 31
Configuring NOL Trend Display 33
Displaying advanced analytical data 34
Configuring Signal Display 35
Annotating Events during the Monitoring Session 35
Reviewing Events during the Monitoring Session 39
Visual Notification of Significant Period Outside a set Threshold 40
7. Tools Screen 41
The Tools screen is not available when a monitoring session is in progress. 41
Exporting and Deleting Data 41
Review Session 44
Additional tools 47
Changing preferences 47
Changing the system language 48
Changing the system Date and Time 49
8. Cleaning and Maintenance 50
1. Cleaning Instructions using MEDIWIPES™ or any other similar disinfection wipes 50
Cleaning and Disinfecting the Monitor Screen 50
Cleaning and Disinfecting the Finger Probe Cable 50
Cleaning and Disinfecting the Finger Probe 50
2. Cleaning Instructions using Clinell universal sanitizing wipes or any other similar disinfection wipes 51
Cleaning and Disinfecting the Monitor Screen 51
Cleaning and Disinfecting the Finger Probe Cable 51
Cleaning and Disinfecting the Finger Probe 51
Maintenance 52
9. Specifications 53
Recommended Separation Distance between Portable & Mobile RF Communications Equipment and PMD-200 55

Essential Performance 55
Technical Data 55
10. Troubleshooting 58
General Troubleshooting 58
Alerts and Informational Signals 59
On-screen notifications 62
11. Connectivity with other systems 66
12. Limited Warranty 67

1. Important Safety Information

Before working with this equipment, make sure that you read, understand, and strictly observe all:

- Warnings
- Cautions
- Notes

Types of Notes

The format and description of the types of notes used in this manual appear below:

Warning

	A warning relates to a situation that could cause serious injury or death to a patient or operator if instructions are not followed.

Caution

	A caution relates to a situation that could cause possible damage to equipment or cause the system to function inaccurately.

Note

	A note contains important user information regarding the use of the system.

Warnings

Warnings

	The instructions in this section are warnings. Be careful to observe all instructions to avoid personal injury or death.

- If you noticed that the package was damaged during shipment, do not install the device.
- Read this User Manual before installation and operation of the PMD-200.
- Review the labeling on the bottom and rear panel of the PMD-200 monitor.
- Make sure that the monitor is installed securely to avoid injury to personnel or patients.
- Do not operate the PMD-200 system without receiving appropriate training.
- Before using the PMD-200 system, verify the integrity of the power cable and the finger probe cable.
- Do not use non-original cables, finger probes, or single use sensors that were not supplied by Medasense or its representative.
- If the system or any of its parts / component / accessories/ packaging including the finger probe, cables and single use sensors is damaged or obstructed, do not use the device.
- Do not use the device in a flammable atmosphere or where concentrations of flammable anesthetics may occur.
- Do not modify or replace any inner component of the PMD-200 system.
- Place all cables carefully and secure them to avoid patient strangulation.
- Do not turn on the device before connecting the finger probe to the system.
- Make sure that the conductive parts of the sensor, finger probe, or connectors do not come in contact with other conductive parts including ground.
- If blood or liquid is spilled on the PMD-200, retest ground leakage current before further use.
- Do not switch the system between patients without starting a new monitoring session.
- Do not remove the patient finger from the finger probe while the device is in operation.
- To avoid cross-contamination, do not reuse a single-use sensor on a different patient.
- To avoid cross-contamination do not use the finger probe on an open wound.
- To maintain signal quality, replace the single use sensor after a maximum of 24 hours of use.

- Do not use the single-use sensor past its expiry date.
- Do not use the NOL index value when an alert about signal quality is displayed on the screen.
- In case of device malfunction or failure, do not open the external cover to fix the device.
- Battery access is permitted only to a trained technician by the usage of special tools and training and even then, the battery pack should not be dismantled in any case but returned to the vendor.
- Do not attempt to replace the system battery.
- Do not expose the PMD-200 to heat or fire.
- Do not attempt to short circuit any of the battery pack wires.
- Do not attempt to remove the battery pack and charge it externally.
- Do not use any battery pack other than the one supplied with the PMD-200 system.
- Do not swap between battery packs of PMD-200 systems.
- Do not drive sharp objects into the battery pack.
- Do not use the PMD-200 system in a Magnetic Resonance Imaging (MRI) environment.
- Do not transport or store the PMD-200 near a source of heat.
- Do not transport or store the PMD-200 in a location where static electricity is present.
- Before using a defibrillator, disconnect the PMD-200 system from the patient.
- When the finger probe is too tight on the finger, tissue damage may occur. Check the finger every few hours and move the finger probe to a smaller finger when required.

Cautions

Caution

	The instructions in this section are cautions. Be careful to observe all instructions to avoid possible damage to equipment or inaccurate system functioning.

- Store the PMD-200 according to the recommended conditions described in the User Manual (see Technical Data).
- If the PMD-200 system will not be used for a long period of time, unplug the device.
- To disconnect the PMD-200 system from the mains, use the plug or the appliance coupler of the power supply cord.

- Make sure that the power cable is connected to the PMD-200 monitor correctly.
- Make sure that there is proper airflow around the PMD-200 system.
- Use the USB port to connect only a USB flash drive or external hard disk drive
- Keep all liquids away from the PMD-200 system.
- Do not position the PMD-200 system so that it is difficult to disconnect the device.
- Make sure that the patient finger is inserted adequately into the finger probe.
- The internal battery is for backup use and not designed for long-term monitoring.
- Clean the PMD-200 system and finger probe prior to initial use and following each use according to the cleaning instructions.
- Do not open the PMD-200 external cover.
- Do not autoclave the PMD-200 system or its accessories.
- After prolonged storage (up to 6 months), it is recommended to charge and discharge battery several times in order to reach maximum performance.
- PMD-200 needs special precautions regarding EMC and needs to be installed and put into service according to the EMC information provided in this user manual. The PMD-200 should be observed to verify normal operation in the configuration in which it will be used.
- Portable and mobile RF communications equipment can affect PMD-200.
- PMD-200 is only operable with original Medasense approved accessories, transducers and cables. Use of unapproved accessories, transducers or cables may result in increased emissions or decreased immunity of the PMD-200.

Equipment Classification

Table 1: Equipment Classification

Parameter	Classification
Degree of protection against electric shock	Class I
Type of protection against electric shock	BF
Type of operation	Continuous
Protection against ingress of liquids	IPX1 Dripping Water Ingress Protection

The system complies with IEC 60601-1 and IEC 60601-1-2 EMC (class A device – Restricted for Hospital and Clinic Use only).

Equipment Symbols

The following table lists the key symbols and their meanings.

Table 2: Equipment Symbols

Symbol	Meaning	Symbol	Meaning
	Date of Manufacture (YYYY-MM) and Country of Origin		Do not use if the package is damaged
	Manufacturer		Serial number
	Catalog number		Type BF applied part
	European compliance Mark of compliance with the European Medical Device Directive	IPX1	IPX1 Dripping Water Ingress Protection
	Refer to instruction manual		Keep dry
	Keep away from sunlight		Temperatures limitation
	Consult instructions for use		Latex-free product
	Do not reuse		Disposal according to electronic scrap ordinance
	Packaging unit		Use-by date

Symbol	Meaning	Symbol	Meaning
	Batch code		Caution, consult accompanying documents
	Authorized representative in the European Community		Atmospheric pressure limitation
	Humidity limitation		Medical Device
	Recycle		Fragile, handle with care
	Unique device identifier		European Importer
	Warning, precaution		Note
	U.S. Federal law restricts this device to sale by or on the order of a licensed practitioner		Authorized representative in Switzerland
	No Heavy Load		

2. Overview

Intended Use

The PMD-200 continuous pain monitor is intended to be used for assessing changes in pain levels. The system monitors the physiological responses to pain using a relative pain index from 0–100, called the *NOL - Nociception Level Index®*. In the NOL index, 0 represents no nociception or pain and 100 represents extreme nociception or pain level.

Indications for Use

The PMD-200 is indicated for use in a clinical setting that requires assessment of changes in pain level during a medical procedure (including, but not limited to: monitoring patient under anesthesia, surgery, post-operative recovery, physiotherapy, pain test, etc.).

The PMD-200 should be used as an adjunct to clinical judgment. Clinical judgment should always be used when interpreting the NOL index in conjunction with other available clinical and vital signs.

The PMD-200 should be used under the direct supervision of a licensed healthcare practitioner or by another caregiver specifically trained for its use.

Contraindications and Limitations

Contraindicated Situations

The PMD-200 should not be used in the following situations:

- Severe cardiac arrhythmias including:
  - Supraventricular tachycardia
  - Atrial fibrillation
  - Atrial flutter
  - Ventricular fibrillation
  - Ventricular tachycardia
  - Cardiac arrest
- During Cardiopulmonary resuscitation (CPR)
- During cardioversion/defibrillation

Unevaluated Conditions

The conditions listed below have not been evaluated during Medasense clinical trials. Physician discretion should be exercised when using the device for the following populations:

- Pediatric patients under the age of 18 years
- Pregnant or lactating patients
- Patients with neuromuscular disease
- Patients suffering alcohol or drug abuse
- Patients undergoing cardiac surgery

When using the PMD-200 with patients with any of these conditions, pay additional attention and exercise additional judgment.

Note

	Physiological conditions such as excessive patient movement, external agents such as blood pressure cuff, tourniquet, etc., low perfusion, electrocautery interference, hypothermia below 35 °C, moisture on sensor may interfere with the monitoring system's ability to detect and display measurements. When signal quality is low or inadequate, an alert is displayed in the status bar (see troubleshooting). Carefully assess the clinical circumstances and use clinical judgment in these limiting conditions.
	Conditions affecting the autonomic nervous system and the volemic status of the patient (e.g. vasoactive medication, positioning, severe hypovolemia) may have a transient effect on NOL values. Carefully assess the clinical circumstances and use clinical judgment in these limiting conditions.

System Description and Operating Concept

The PMD-200 system consists of 4 main components:

- **Monitor** – acquisition and display of physiological signals and NOL index and trend graph.
- **Software** includes two main components:
  - Calculation of the NOL index based on physiological parameters extracted from signals.

  - User interface – displays physiological signals, NOL index and trend graph.
- **Finger probe** –includes the following sensors:
  - Photoplethysmogram (PPG or Pleth)
  - Thermistor for peripheral temperature (TMP or Skin Temp)
  - A 3-axis accelerometer for movement (ACC or Movement).
  - Connectors for the Galvanic skin response sensor (GSR or Conductance)
- **Single use sensor** (connected to the finger probe) – includes the following sensor:
  - Bio-impedance Galvanic skin response sensor (GSR or Conductance)

The NOL index is a relative, non-linear measure with a range of 0–100, where 0 represents no pain /nociceptive response and 100 represents extreme pain/nociceptive response.

The NOL index and trend are intended to support clinical decisions concerning the administration of analgesic medications.

Clinical evidence[1,2,3,4]suggests the following guidelines for surgical procedures under general anesthesia:

- NOL above 25 for more than one minute (whether constant or fluctuating) may indicate the patient requires additional analgesic therapy. Higher values indicate a stronger nociceptive response.
- NOL between 0–25 represents an appropriately suppressed physiological response to noxious stimuli and may indicate adequate analgesia.
- NOL below 10 for more than one minute, **during a painful stimulation,** may indicate excessive anti-nociception and reduction of analgesics may be considered.
- The NOL index cannot anticipate noxious stimuli and thus a minimal level of analgesics should always be maintained.

Note

[1] Meijer, F et al/Reduced postoperative pain using Nociception Level-guided fentanyl dosing during sevoflurane anaesthesia: a randomised controlled trial/ British Journal of Anaesthesia 2020 September

[2] Meijer F et al/ Nociception-guided versus Standard Care during Remifentanil–Propofol Anesthesia: A Randomized Controlled Trial/Anesthesiology 2019 Feb.

[3] Ledowski, T., Schlueter, P. & Hall, N. Nociception level index: do intra-operative values allow the prediction of acute postoperative pain?. J Clin Monit Comput (2021).

[4] Martini CH et al Ability of the Nociception Level (NOL), a multiparameter composite of autonomic signals, to detect noxious stimuli during propofol-remifentanil anesthesia Anesthesiology 2015 Sept.

	The PMD-200 should be used as an adjunct to clinical judgment. Clinical judgment should always be used when interpreting the NOL index and trend line in conjunction with other available clinical and vital signs.

Training

Before working with the PMD-200, users should receive adequate training on its safe and effective use. Make sure that training is received in accordance with local laws and legal regulations. For information about training, contact your Medasense representative.

Note

	Further education resources are available on the Medasense website and Academy at www.medasense.com and the NOL pocket guide for clinicians is available by request from info@medasense.com

Screen Layout

To enable easy navigation, the screen is divided into panes according to the types of information presented.

The details of screen content vary depending on the stage of the procedure. However, the general layout remains the same throughout all stages. The general layout is illustrated in the Monitoring Screen presented below:



Figure 1: Monitoring Screen Layout

1	Status bar: Power indication, system clock, and alert display
2	Signal pane
3	NOL index pane
4	NOL trend pane with threshold level markers and review annotations button
5	Menu bar (with START/STOP button)

3. System Components

This chapter describes the parts that make up the PMD-200 monitoring system.



Figure 2: Schematic Diagram of the PMD-200 System

Description	Manufacturer	Model
PMD-200 Monitor	Medasense Biometrics	PMD200-2
Finger Probe	Medasense Biometrics	FP200-2
Single-use Sensor (PMD-200 Sensor)	Medasense Biometrics	MEK-0002

Monitor

Front Panel

Figure 3: Monitor Front Panel

The monitor front panel includes:

- 8.4'' (21.3 cm) color LCD touchscreen.
  The interface is designed for easy operation also when wearing surgical gloves.
- An ON/OFF Power button.
  When the monitor is ON, the button is lit white. When the monitor is OFF, the button is lit blue.
- A socket for the finger probe.

Back Panel

The PMD-200 back panel includes an RS232 port allowing connectivity to Medasense approved systems (see section 11). The connectivity port can be closed using the built-in cover when not in use.



Figure 4: Monitor Back Panel



Figure 5: Monitor Back Panel - Connectivity Configuration. A. Closed connectivity port. B. Open connectivity port.

The PMD-200 back panel includes:

- Back Panel Cover with screw
- Power switch
- Socket for power cable
- Mounting clamps for mounting the monitor on a pole or rails
- A built-in carrying handle
- RS-232 connectivity port

Side Panel

Figure 6: Side Panel

The PMD-200 side panel includes a standard USB port for connecting an external device or downloading data.

Note

	Use the USB port to connect only: • USB flash drive • External hard disk drive • USB keyboard or mouse

Software

The PMD-200 System software consists of proprietary software and proprietary algorithms for the calculation of the NOL index.

The proprietary software and algorithms control the signal acquisition and analysis, data management and graphic user interface.

Finger Probe

The finger probe is one size and can be connected to any of the patient's fingers. The finger probe is a reusable part intended to be used multiple times, and connects to the system through a 2.8m (9 ft.) cable.

It includes the following sensors:

- Photoplethysmogram (PPG or Pleth)
- Thermistor for peripheral temperature (TMP)
- A 3-axis accelerometer for movement (ACC or Movement).
- Connectors for the Galvanic skin response sensor (GSR or Conductance)

Figure 7: Finger Probe and Cable

Caution

	The finger probe should be cleaned prior to initial use and following each use according to the instructions in section 8

Single use Sensor

The single-use sensor is intended for a single patient and must not be transferred between patients.

The single-use sensor is comprised of a removable adhesive protection, GSR sensor and a sticky hydrogel.

The single-use sensor is connected to the upper side of the finger probe.

The expiry date of the single use sensor is clearly marked on the single-use sensor packaging .

Figure 8: Single Use Sensor with pack

Warnings

	• Do not use an expired sensor. • During long term monitoring, replace the single use sensor at least once every 24 hours. • Do not re-use the single use sensor on a different patient.

Power Cable

The power cable connects the PMD-200 monitor to the electrical socket.

Warnings

	Do not use non-original cables. Ensure that the power cable is connected correctly.

Power Requirements

AC Voltage Input: 100–240 VAC, 50-60 Hz, 700 mA.

Battery Backup

If there is a loss of AC power, the monitor continues uninterrupted operation for a period of up to 30 minutes. When supply of AC power resumes, the system switches back automatically to AC power mode.

The power status is indicated in the status bar at the top of the screen. A green battery with a plug indicates AC power. A red battery indicates battery power.

AC Power

Battery Power

Figure 9: Power Status Indications

The internal battery is rechargeable. The maximum charging time is 2 hours for a full charge.

When the system is connected to AC power, the battery charges automatically.

4. Installation and Setup

Selecting a Location

When selecting a location for the PMD-200 system, follow these guidelines:

- Recommended: Keep the room temperature between 15°C and 25°C (59 °F–77°F). Do not use PMD-200 if room temperature is below 10°C (50°F) or above 35°C (95°F).
- Do not place the PMD-200 system where it is exposed to direct sunlight or constant vibrations.
- Do not place the PMD-200 system close to heaters or air conditioners
- Make sure that there is enough space to perform regular system maintenance procedures.
- The PMD-200 system may be mounted on a pole or on the bed rails using the clamp on the monitor back panel.



Figure 10: Mounting Clamp

Warnings	
	▪ Make sure that the monitor is installed securely to avoid injury to personnel or patients ▪ If the system or any of its parts / component / accessories/ packaging including the finger probe, cables and single use sensors is damaged or obstructed, do not use the device ▪ Do not use the device in a flammable atmosphere or where concentrations of flammable anesthetics may occur ▪ Do not modify or replace any inner component of the PMD-200 system ▪ Place all cables carefully and secure them to avoid patient strangulation

	▪ Make sure that the conductive parts of the sensor, finger probe, or connectors do not come in contact with other conductive parts including ground ▪ Do not transport or store the PMD-200 near a source of heat

Caution

⚠	▪ Do not place the PMD-200 system where it is exposed to direct sunlight or constant vibrations. ▪ Do not place the PMD-200 system close to heaters or air conditioners ▪ Store the PMD-200 according to the recommended conditions described in the User Manual (see Technical Data) ▪ If the PMD-200 system will not be used for a long period of time, unplug the device ▪ Make sure that there is proper airflow around the PMD-200 system

Connecting the System

1. Connect the dedicated power cable to the PMD-200 and to the electrical outlet.
2. Connect the finger probe cable to its socket on the PMD-200 front panel.
   Make sure to insert the projection on the connector into the groove in the socket.

Figure 11: Connecting the Finger Probe Cable

Powering ON the PMD-200

Warnings

	Do not use non-original cables, finger probes. **Do not re-use the single use sensor**. Ensure that the power cable is connected correctly.

1. Make sure that the Power switch on the back panel of the monitor is switched ON (–).

Figure 12: Power Switch on Back Panel

2. Press the Power button on the front panel of the monitor. Once On, the power button will be lit in white.

Figure 13: Power Button ON

The system tests communication between the monitor and the sensors. During initialization, the Loading screen is displayed.

Figure 14: Loading screen

When communication is established, the Home Screen is displayed.



Figure 15: Home Screen

5. Monitoring Mode

Monitoring mode of the PMD-200 involves a simple 3-step process:

1. Connecting the patient to the PMD-200 via the finger probe and single use sensor and verifying the connection by checking signal quality on screen.
2. Starting the monitoring session.

   After pressing the START button, a short automatic calibration process begins. After the calibration, monitoring begins.

   The Monitoring Screen displays real-time information relating to patient pain/nociceptive response.
3. Stopping the monitoring session.
   It is imperative to press STOP by the end of each monitoring session, to make sure the monitoring session is saved and can be exported if desired.

This chapter contains the instructions for operating PMD-200 in Monitoring mode.

In addition to basic use of PMD-200 in Monitoring mode, advanced tools for annotation, data display configuration, and export are available (see next chapter - Advanced Tools).

1. Connecting the Patient to the PMD-200

Warnings	
	• Make sure you turn ON the system only after the finger probe is connected to the monitor. • Press START only after the finger probe has been connected to the patient finger and adequate signals are measured. • Make sure that the conductive parts of the sensor, finger probe, and connectors do not come in contact with other conductive parts including earth. • To avoid cross-contamination, **do not reuse** a single-use sensor. • To avoid cross-contamination do not use the finger probe on an open wound. • If the finger probe is secured too tightly, tissue damage may occur. Check the finger every few hours and move the probe to an alternative or smaller finger when required.

Note	
	• Make sure you turn the system ON only after the finger probe is connected to the monitor. • Press START only after the finger probe has been connected to the patient finger and adequate signals are measured.

1. Make sure that all system connections are set up correctly (see Connecting the System), including the finger probe connection to the monitor.
2. Connect the single-use sensor to the finger probe.

Once the PMD-200 is turned on, the home screen will display instructions.

Note

	When connecting a single use sensor, make sure that: • An original Medasense single-use sensor is being used • A new sensor is being used for each patient • The sensor snaps are well connected to the cavities in the finger probe

3. Choose the patient's most suitable finger, in size, length and volume.
4. Remove the liner from the adhesive sensor pad.

Figure 16: Removing the Liner

5. Insert the patient's finger at a 30^{o} angle so the fingertip touches the stopper at the end of the probe. Make sure that the phalanx joint does not align directly above the pleth sensor.



Figure 17: Correct placement of the finger into the Finger Probe

Figure 18: signal alerts are showing when finger is not properly inserted

Note

	Do not press START before securely connecting the patient finger to the finger probe and verifying no signal alerts are displayed.

6. Attach the sides of the sensor pad to the sides of the finger.

Remove the rest of the liner and wrap the adhesive strap around the finger probe to ensure continuous contact without wrapping too tightly.



Figure 19: Adhesive Strap around Finger

Caution

⚠	• Make sure that the patient finger is inserted securely into the finger probe and remains in place during the monitoring session. • DO NOT place the finger probe on the same hand as other devices that may interfere with blood flow such as non-invasive blood pressure cuffs or tourniquets.

2. Starting the Monitoring Session

1. Observe the signals pane and verify good signal quality. Make sure the Pleth signal is cyclic, strong and adequate. If the measured Pleth signal is too weak or of low quality, a notification (see below) will appear advising the user to reposition the finger for better signal strength and quality. In these cases, check that perfusion is adequate, and move the finger slightly forwards or backwards inside the finger probe to achieve better alignment with the Pleth sensor.



Figure 20: Pleth signal sub-optimal message

2. Press the START button (

).

   The system begins calibrating for the specific patient according to the initial signals acquired from the patient. This may take up to 30 seconds. The Calibration Screen is displayed.



Figure 21: Calibration Screen

In the Information pane (1), the time and battery indication are displayed, as well as alerts and informational signals about issues during the procedure

In the Signals pane (2), the Pleth (PPG) signal and the Conductance (GSR) signal are displayed.

In the NOL Index Value pane (3), the status message Calibrating is displayed. No index value is displayed yet.

In the Trend pane (4), no trend is displayed yet. The session time (time elapsed from when the START button was pressed) is displayed.

In the Menus toolbar (5), you can activate and deactivate a menu/screen by pressing the relevant button:

- Pressing

will start a new procedure from the home screen and initiate the calibration process (see above)
- Pressing

will stop the procedure and save the procedure recording (see “Stopping the Monitoring session”)
- Pressing

will activate the patient menu (see “adding patient details”)
- Pressing

will activate the NOL trend menu (see “Configuring NOL Trend Display”)
- Pressing

will activate the signals menu (see Configuring Signal Display)
- Pressing

will activate the events annotations menu (see “Annotating Events during the monitoring session”)
- Pressing displays the tools screen, where it is possible to review, export and delete procedure recordings, set systems preferences and view

system information (see relevant sections in “Advanced Tools”)
Note that the tools screen is not available during a monitoring session.

When calibration is completed, the Monitoring Screen appears with the NOL index value displayed.



Figure 22: Monitoring Screen

3. Review the information according to the guidance in Starting a Monitoring Session 2 described above.

   In the Signal pane, the Pleth (PPG) signal and the Conductance (GSR) signal are displayed by default.

   Temperature (Skin Temp) and Movement (ACC) signals are also available for display. For instructions about configuring signal display, see advanced tools section.



Figure 23: Signal Pane Showing 4 Signal Types

Note

	The signal waveforms are displayed in order to assist the user in confirming finger positioning and signal input adequacy as part of the setup process. The signals should not be considered as vital sign measurements.

In the NOL Index pane, the NOL index value (0–100) is displayed. A bar indicating the NOL value is displayed in the right of the pane. The bar can be shown in white or color-coded according to user preferences. When color-coded, for NOL values under the lower user-set threshold, the indicator bar will be white. For values over the upper user-set threshold, the indicator will be red. For values between the two user-set thresholds, the indicator bar will be Green. See "Configuring NOL Trend Display" to learn how to set the upper and lower threshold.

Factory default for the upper threshold is 25 and for the lower threshold 0, based on existing clinical evidence (section 2).



Figure 24: Examples of NOL Pane Showing NOL Index Value and Indicator Bar

In the Trend pane, a continuous graph of the NOL index over time (minutes or hours as set by user) is displayed. The default display is 10 minutes. For instructions about configuring the display of NOL index and trend, see Configuring NOL Trend Display.

If so configured, the system will display 2 horizontal lines representing the user-defined thresholds.



Figure 25: Trend Pane

When signal quality is low or inadequate, an alert is displayed in the information pane (see Alerts and **Informational Signals**)

Warning

	Do not use the NOL index value when an alert about signal quality is displayed on the screen.

3. Stopping the Monitoring Session

1. Press the STOP button (

).
   A confirmation message is displayed.



Figure 26: Confirmation Message for Stopping Monitoring

2. To stop the monitoring session, press Stop Monitoring.
   The system stops the monitoring session and saves the data. The Home Screen is displayed.
   If you do not press Stop Monitoring within 20 seconds, monitoring continues automatically.



Figure 27: End of Monitoring Session

3. Remove the finger probe and the sensor from the patient finger. Discard used single-use sensor as medical waste.

4. Shut down the system by pressing the Power button on the front panel of the monitor. Shut down menu will appear on screen.
5. Press Shut down now to power OFF the device or Cancel to abort shutdown request.

Figure 28: Shut Down Menu

Once the system is shut down, the power button will be lit in Blue.

Figure 29: Power Button OFF

Warning

	Make sure to Stop monitoring and Start a new monitoring session between new patients.

Caution

	If the PMD-200 system will not be used for a long period of time, unplug the device.

6. Advanced Tools

The actions described in this chapter are not required for basic use of the PMD-200 in Monitoring mode. These actions enable changing the display of information on the screen, presenting advanced analytical data about the procedure, adding information to the saved monitoring session data, updating user/regional preferences and exporting the monitoring session data.

Adding Patient Details

Prior to or during a monitoring session, you can add patient information that will be saved with the monitoring session data.

Note

	Adding patient data will not affect NOL calculations in any way. This option is offered only to assist in recording procedure information.

1. On the menu bar, press the PATIENT button (PATIENT).

   The Patient data fields are displayed for updating patient data, in either metric or imperial units of measurements (see “Tools screen” for setting up units of measurement).



Figure 30: Patient Data Fields (2 options)

2. Press the text box below the data field that you want to update.

   A virtual keyboard will be displayed.

Figure 31: Virtual Keyboard

3. Using the virtual keyboard, type the information that you want to enter:

   Age: Type a numeral (up to 120) for the patient's age in years.

   Weight: Type a numeral for the patient's weight in kilograms (0-300) or lbs. (0-665) (see “tools screen” for setting up units of measurement)

   Height: Type (a) numeral(s) for the patient's height in centimeters (50-250) or feet and inches (1’8”-8’2”) (see “tools screen” for setting up units of measurement).

   Surgery: Type free text for the surgery type.

   Notes: Type free text for any required additional notes.

4. On the keyboard, press the Insert key (Insert) to enter the data in the field.

   If the information that you typed is not in the correct format or out of the defined range, a message appears prompting you to correct it.

Figure 32: Invalid data inserted

5. Repeat Steps 2-4 for any other fields that require update. It is also possible to edit or delete information that was already entered.
6. To close the Patient option bar and return to the Monitoring screen, press the PATIENT button (PATIENT) or the X button (X).

Configuring NOL Trend Display

You can change how the NOL trend is displayed in the NOL Trend pane and display live analytical information (if option is enabled – see “tools screen” on how to activate live analytics).

1. On the menu bar, press the NOL TREND button (NOL TREND).
   The NOL TREND option bar is displayed.



Figure 33: NOL TREND Option Bar without live analytics

2. Use the buttons on the NOL TREND option bar to configure the NOL trend display:
   - Time Scale (x): Use these buttons to select the time interval displayed in the Trend pane (1 min, 2 min, 5 min, 10 min, 30 min, 1 hr, 2 hr, 3 hr, 4 hr, and more up to 24 hours. When choosing “total session” display will be adjusted to the closest whole hour).
   - Low Threshold: Use these buttons to set the lower threshold. Any value between 0 (threshold off) and the upper threshold (see below) can be chosen. Factory default for this value is set at zero (0), i.e. threshold inactive.
   - High Threshold: Use these buttons to set the upper threshold, above which the NOL value may indicate insufficient dosage of analgesia. Any value can be chosen between the lower threshold (see above) and 100 (threshold off). Factory default for this value is set at 25.

Note

	• This feature may be disabled by your local administrator. • Always evaluate the clinical suitability of thresholds when guiding analgesia based on NOL trends.

3. To close the NOL TREND option bar and return to the Monitoring screen, press the NOL button (NOL TREND) or the X button (X).

Displaying advanced analytical data

If the “Live Analytics” option is enabled (see setting regional and user preferences), the NOL pane will now include statistical insights about the current procedure, and the NOL value will show above the NOL color bar (see figure 34)

1. press the NOL TREND button (NOL TREND).



Figure 34: NOL TREND Option Bar with live analytics enabled

The table and accompanying color-coded pie chart present the amount of time (over the selected time base for analytics) that the NOL value was within each range based on the upper and lower thresholds as set by the user: above upper threshold in red, below lower threshold in white or between both in green. The table will also include the mean NOL value (MV) above, below or between selected ranges.

2. Adjust the time base for analytics calculation by pressing the + and – signs. The time base is always calculated retrospectively from the present moment. Therefore choosing “30 minutes” will display the analysis for the last 30 minutes of the procedure.

NOL – details the chosen ranges

% time -details the percentage of time spent within each chosen range

MV – details the mean NOL value (within, above or below the chosen threshold).

Configuring Signal Display

You may select the signals displayed in the Signal pane:

1. On the menu bar, press the SIGNALS button. The Signal option bar is displayed.



Figure 35: Signal Option Bar

2. Use the buttons on the Signal option bar to configure the signal display and select which of the 4 available signals are displayed (active signals will be colored):
    - Pleth **(PPG,** Plethysmograph pulse wave)
    - Conductance **(GSR,** Galvanic Skin Response)
    - Skin Temp (Peripheral temperature)
    - Movement **(ACC,** Accelerometer)
3. To close the Signal option bar and return to the Monitoring screen, press the SIGNALS button (SIGNALS) or the X button (X).

Annotating Events during the Monitoring Session

You can annotate any special event that occurs during the monitoring session.

4. On the menu bar, press the EVENTS button. The Event option bar is displayed.



Figure 36: Event Option Bar

5. Press the relevant category for the event:

   Medication

   Stimuli

   Clinical

   Favorites

   The annotation time is now saved and displayed in the relevant event category window.



Figure 37: Event Annotation Options with Annotation Time Displayed

The time of annotation is marked on the trend graph by a dotted vertical line.



Figure 38: Annotation Displayed on NOL Trend

6. Choose the selected annotation from the menu.



Medication



Stimuli



Clinical



Favorites

Figure 39: Event Annotation Options

When the annotation is selected, it is displayed above the EVENTS tab.



Figure 40: Annotation and Annotation Time Displayed

If you want to permanently set an annotation that is not listed in the menu, press the edit icon ( ) on the annotation options window.

The annotations will become highlighted in light green:



Figure 41: Annotation Options in Edit mode

Select an existing annotation space or an empty box to add free text, or to edit existing text. The virtual keyboard will be displayed (see figure 32).

Type the required free text and press the Insert button (

).

To exit the edit mode and to choose an annotation, press the edit icon ( ), make sure that the script on the annotations buttons reverted to white and choose the required annotation.

To reset the annotation menu back to the default, press the “Restore Default” button and when prompted press “Yes” to confirm restoring to default setting.



Figure 42: Restore default

7. To exit the annotation category window, press the X ( ) icon.
8. To add an event which doesn’t exist in any of the categories, press the Custom Event button ( ) (the annotation time will now be saved and displayed), then enter free text by using the keyboard.
9. To close the Event option bar and return to the Monitoring screen, press the EVENTS button ( ) or the X button ( ).

Reviewing Events during the Monitoring Session

You can review previously annotated events during the monitoring session.

1. Set the NOL trend view to the appropriate time frame so the event of interest is visible on the trend (see “configuring NOL trend”).
2. Press the button on the upper right side of the trend pane. The last reviewed annotation content is displayed above the NOL trend, and the event marker is highlighted.
3. Press the right or left arrow to navigate between annotations in descending (left) or ascending (right) chronological order, until the correct event is highlighted.
4. Press the button again or wait for approximately 30 seconds to close the previous annotations viewer.



Figure 43: Reviewing a previous annotation

Visual Notification of Significant Period Outside a set Threshold

You can set a visual notification to indicate that the NOL Trend has been mostly out of threshold for a significant period of time. This option is not available if disabled by the local administrator.

1. Press the 'NOL Trend' tab.
2. Press the button on the right side of the trend pane.

a dialog box will be displayed.

3. Set the significant period of time.
4. The NOL value will blink whenever the NOL Trend is above the high threshold or below the low threshold for at least 80 % of the significant period. For example, if the significant period is set at 10 min, any time the NOL trendline will be above the high threshold or below the low threshold for 8 out of the last 10 min, the NOL value will blink.
5. Blinking may be stopped by pressing the NOL value.
6. Setting the significant period to 0 min will turn off this feature.
7. By default, this feature is turned off.

7. Tools Screen

Note

	The Tools screen is not available when a monitoring session is in progress.

Exporting and Deleting Data

You can export the recorded data and annotations through the tools screen.

1. Connect a USB flash drive or external hard disk drive in the USB port on the side panel of the monitor.
2. On the menu bar, press the tools button ( ).

   On the upper left side of the screen, is a list of procedure recordings. The recordings are arranged chronologically (newest on top) and their filenames are in the **YYYY-MM-DD_HHmm** format, based on their individual start time.

Figure 44: Tools Screen

3. On the recordings list on the left of the screen, select the recording(s) that you want to export. You can choose multiple (adjacent) recordings by dragging your finger across the required recordings.

4. On the actions menu in the center of the screen, press one of the options:
   - Press Export Folder to USB to export all the raw data of a specific monitoring session including the "Review Session" PDF file.
   - Press Export Excel File to USB to export a comma-separated Excel (.csv) file with the following parameters of a specific monitoring session:
     - Time
     - NOL index
     - Heart rate
     - Annotations

   The .csv file is saved both on the USB flash drive and in the patient folder.

   The export process begins and a progress indicator is displayed.

Figure 45: Export Progress Indicator

When the export is completed, a message is displayed.



Figure 46: Examples of Completed Export Messages

5. Click OK on the message.

   If a USB flash drive is not connected, a message is displayed.

Figure 47: No USB Message

If the system cannot export the data, a message is displayed.



Figure 48: Unsuccessful Export Message

6. To close the Tools screen, press the button.

From the Tools screen, you can also delete recordings.

1. On the recording list on the left of the screen, select the recording(s) that you want to delete.
2. On the actions menu in the center of the screen, press 

   A message is displayed asking for confirmation.

Figure 49: Confirmation Message

3. To delete the recording, press **Yes**.
   To cancel the deletion, press **Cancel**.

Note

	File deletion is permanent. After a file is deleted, its data cannot be restored.

When the deletion is completed, a message is displayed.



Figure 50: Completed Deletion Message

If there are no folders to delete, the following message will appear:



Figure 51: No folders to delete

Review Session

The Review Session option allows the user to review a previous recording session once it has been properly concluded.

1. On the recording list on the left of the screen, select the file that you want to review.
2. On the actions menu in the center of the screen, press 

A procedure recording will be displayed on the PMD-200 screen. Navigate between pages by pressing the right / left arrows at the bottom of the screen. The first page includes a summary of the NOL trend for the entire recording session, including the upper and lower thresholds as they were set at the end of the procedure. If the “live analytics” option was enabled during the procedure, the second page will include a view of the live analytics information for the entire procedure (on the left) as well as the last displayed view for the user at the time the procedure was stopped. If the session was longer than 30 minutes, additional pages will include 30 minutes segments of the session. In this case, for clarity, annotations will only be displayed on the 30 minutes segments (first page with full procedure will not display annotations).



Figure 52: Review session - Full session

Figure 53: Review session – Analytics page



Figure 54: Review session - 30 minutes segment, including annotations

If the session was not properly concluded and saved (by pressing the “Stop” button) the system will display the following message:

Figure 55: Review mode unavailable

If there are no folders to review, the system will display the following message:



Figure 56: No folder to review

Exporting a folder to an external USB storage device enables the user to display the review session as a PDF file on any computer.

Additional tools

The **About** option displays information about the PMD-200 software (SW), firmware (FW) versions and the remaining free space on the internal hard drive.

The **Tech Mode** (Technician mode) option is password-protected. It is for use by Medasense technical personnel for service and maintenance procedures requiring access to the PMD-200 operating system and restricted software, and by local administrators to manage site preferences.

To close the Tools menu and return to the Home screen, press the button.

Changing preferences

You can change the system preferences through the Tools screen. This option is not available when a monitoring session is in progress, or if disabled by the local administrator.

3. Access the Tools screen by pressing
4. Set the units of measurements by choosing between Imperial (Feet/Inches and Lbs.) or Metric (cm and Kg).
5. Set the NOL value bar to color-coded (white – under lower threshold, green – between both thresholds, red – above upper thresholds) or black & white (white bar will show on black background)
6. Enable or disable the analytics capabilities. When enabled, analytics data will be accessible in the “NOL trend” screen.

Figure 57: Tools Screen

Changing the system language

You can change the system display language from the Tools screen. This option is not available when a monitoring session is in progress.

1. Access the Tools screen by pressing
2. On the bottom right of the Tools screen, press the button
3. Pressing the Language button opens a list of all available languages.
   The current system language is marked with a "-".
4. Choose a new language and press OK for the change to take place.



Figure 58: Language Selection Menu

After pressing OK, a restart message is displayed.

The user can restart the system by pressing Restart Now or wait 20 seconds for the system to restart automatically.



Figure 59: System Reset Confirmation Before Language Change

Changing the system Date and Time

You can adjust the system Date or Time while in Standby mode. This option is not available when a monitoring session is in progress.

1. Press on the Display Clock on the upper right corner of the screen.
2. A time and date configuration window will open.
3. Adjust the date/time by pressing "+" or "-" until the correct date/time is displayed. Press Change and Restart Now for the changes to take effect.

Figure 60: Change Date/Time screen

In case of invalid date, an error message will be displayed. Press OK to close the error message.

Figure 61: Invalid Date message

Please correct the invalid values marked in red and press Change again.



Figure 62: Invalid values marked in red

8. Cleaning and Maintenance

Caution

	The PMD-200 system and finger probe should be cleaned prior to initial use, and following each use.

Cleaning of the system and the finger probe should be performed using one of the two validated methods described below depending on the type of wipes used.

1. Cleaning Instructions using MEDIWIPES™ or any other similar disinfection wipes

Clean any blood or liquid spilled on the monitor, finger probe, or connecting cable immediately. Dried blood is very difficult to remove.

After cleaning, wipe the end of the connector with alcohol and allow it to dry completely. Residual moisture inside the connector may affect monitoring performance.

Cleaning and Disinfecting the Monitor Screen

Use 2-3 fresh disposable disinfecting wipes to wipe thoroughly all surfaces with special care to holes, edges and slots. Contact time should be at least 3 minutes.

Cleaning and Disinfecting the Finger Probe Cable

After each usage, disinfect the finger probe and the connecting cable.

1. Use 1-2 fresh disposable disinfecting wipes to wipe thoroughly the cable attached to the finger probe. Contact time should be at least 1 minute.
2. Visually inspect that the cable is clean from gross debris.
3. Leave the cable to be air dried, or alternatively, use a dry, lint free cloth to dry the surface of the cable.

Cleaning and Disinfecting the Finger Probe

4. Use 2-3 disposable disinfecting wipe to remove any gross debris.
5. Visually inspect all parts to ensure that no residues or debris remained prior to continuing to the next step.
6. Use 2-3 fresh disposable disinfecting wipes to wipe thoroughly all surfaces with special care to GSR electrodes button holes, edges and slots. Optionally, use sterile swabs to push the wipes into the slots and button holes, to verify good contact with the disinfection agent. Contact time should be at least 3 minutes.

7. Moisten a sterile lint free cloth with distilled water and wipe all surfaces for 30 seconds (make sure that the cloth is moist and not fully soaked with water).
8. Leave the finger probe to be air dried, or alternatively, use a dry, lint free cloth to dry the surfaces.

2. Cleaning Instructions using Clinell universal sanitizing wipes or any other similar disinfection wipes

Clean any blood or liquid spilled on the monitor, finger probe, or connecting cable immediately. Dried blood is very difficult to remove.

After cleaning, wipe the end of the connector with alcohol and allow it to dry completely. Residual moisture inside the connector may affect monitoring performance.

Cleaning and Disinfecting the Monitor Screen

Use 2-3 fresh disposable disinfecting wipes to wipe thoroughly all surfaces with special care to holes, edges and slots. Contact time should be at least 5 minutes.

Cleaning and Disinfecting the Finger Probe Cable

After each usage, disinfect the finger probe and the connecting cable.

1. Use 1-2 fresh disposable disinfecting wipes to thoroughly clean the cable attached to the finger probe. Contact time should be at least 3 minutes.
2. Visually inspect that the cable is clean from gross debris.
3. Leave the cable to be air dried, or alternatively, use a dry lint free cloth to dry the surface of the cable.

Cleaning and Disinfecting the Finger Probe

4. Use 2-3 disposable disinfecting wipes to remove any gross debris.
5. Visually inspect all parts to ensure that no residues or debris remained prior to continuing to the next step.
6. Use 2-3 fresh disposable disinfecting wipes to thoroughly clean all surfaces, paying special care to GSR electrodes button holes, edges and slots. Optionally, use sterile swabs to push the wipes into the slots and button holes, in order to verify good contact with the disinfection agent. Contact time should be at least 5 minutes.
7. Moisten a sterile lint free cloth with distilled water and wipe all surfaces for 30 seconds (make sure that the cloth is moist and not fully soaked with water).
8. Leave the finger probe to be air dried, or alternatively, use a dry, lint free cloth, to dry the surfaces.

Warning

	If blood or liquid is spilled on the PMD-200, retest ground leakage current before further use.

Caution

	Do not autoclave the PMD-200 system or its accessories.

Maintenance

The PMD-200 Monitor is designed so that no periodic maintenance is required.

- Leakage current is a primary indicator of electrical shock hazard for personnel who touch any of the device's outer surfaces. Static electricity tests have been conducted on the PMD-200 monitor to ensure that the leakage current meets safety standards of IEC 60601-1.

Medasense recommends performing a leakage current test:

- In the event of blood or liquid spill on the system or its components
- Immediately after a major surge in the electrical system

9. Specifications

The PMD-200 is intended for use in the electromagnetic environment specified below.

Table 3: PMD-200 electromagnetic environment compatibility

Emissions test	Compliance	Electromagnetic environment - guidance
RF emissions CISPR 11	Group 1	The PMD-200 uses RF energy only for its internal function. Therefore, its RF emissions are very low and are not likely to cause any interference in nearby electronic equipment
RF emissions CISPR 11	Class A	The PMD-200 is suitable for use in all establishments other than domestic and those directly connected to the public low-voltage power supply network that supplies buildings used for domestic purposes.
Harmonic emissions IEC 61000-3-2	Class A	
Voltage fluctuations/flicker emissions IEC 61000-3-3	Complies	

Note

The EMISSIONS characteristics of this equipment make it suitable for use in industrial areas and hospitals (CISPR 11 class A). If it is used in a residential environment (for which CISPR 11 class B is normally required) this equipment might not offer adequate protection to radio-frequency communication services. The user might need to take mitigation measures, such as relocating or re-orienting the equipment.

Table 4: Electromagnetic Immunity

Immunity test	IEC 60601 level	Compliance level	Electromagnetic environment - guidance
Electrostatic discharge (ESD), IEC 61000-4-2	8 kV contact 15 kV air	8 kV contact 15 kV air	Floors should be wood, concrete or ceramic tile. If floors are covered with synthetic material, the relative humidity should be at least 30 %.
Electrical fast transient/burst, IEC 61000-4-4	2 kV for power supply lines 1 kV for SIP/SOP lines	2 kV for power supply lines	Mains power quality should be that of a typical commercial or hospital environment
Surge, IEC 61000-4-5	1 kV line to line 2 kV line to earth	1 kV line to line 2 kV line to earth	Mains power quality should be that of a typical commercial or hospital environment.
Voltage dips and interruptions on power	0 % U_T for 0,5 cycle	0 % U_T for 0,5 cycle	Mains power quality should be that of a typical commercial or hospital

Immunity test	IEC 60601 level	Compliance level	Electromagnetic environment - guidance
supply input lines IEC 61000-4-11	0 % U_T for 1 cycle 70 % U_T for 25/30 cycles 0 % U_T for 250/300 cycles	0 % U_T for 1 cycle 70 % U_T for 25/30 cycles 0 % U_T for 250/300 cycles	environment. If the user of the equipment requires continued operation during power mains interruptions, it is recommended that the equipment be powered from an uninterruptible power supply or a battery.
Power frequency magnetic field, IEC 61000-4-8	30 A/m	30 A/m	Power frequency magnetic fields should be at levels characteristic of a typical location in a typical commercial or hospital environment.
NOTE: U_T is the AC mains voltage prior to application of the test level.			

Table 5: Immunity tests

Immunity test	IEC 60601 level	Compliance level
IEC 61000-4-6 Conducted RF	3 Vrms 150 kHz to 80 MHz 6 Vrms in ISM bands (6.765 MHz to 6.795 MHz; 13.553 MHz to 13.567 MHz; 26.957 MHz to 27.283 MHz; and 40.66 MHz to 40.70 MHz) and amateur bands (1.8 MHz to 2.0 MHz, 3.5 MHz to 4.0 MHz, 5.3 MHz to 5.4 MHz, 7 MHz to 7.3 MHz, 10.1 MHz to 10.15 MHz, 14 MHz to 14.2 MHz, 18.07 MHz to 18.17 MHz, 21.0 MHz to 21.4 MHz, 24.89 MHz to 24.99 MHz, 28.0 MHz to 29.7 MHz and 50.0 MHz to 54.0 MHz)	[*V*] = 3 Vrms [*V*] = 6 Vrms
IEC 61000-4-3 Radiated RF	3 V/m 80 MHz to 2.7 GHz	[*E*] = 3 V/m
Proximity fields from RF wireless communications equipment	385 MHz	27 V/m
	450 MHz	28 V/m
	710 MHz	9 V/m
	745 MHz	
	780 MHz	
	810 MHz	28 V/m
	870 MHz	
	930 MHz	
	1720 MHz	28 V/m
	1845 MHz	
	1970 MHz	
	2450 MHz	28 V/m
	5240 MHz	9 V/m
	5500 MHz	
	5785 MHz	

Recommended Separation Distance between Portable & Mobile RF Communications Equipment and PMD-200

WARNING: Portable RF communications equipment (including peripherals such as antenna cables and external antennas) should be used no closer than 30 cm (12 inches) to any part of the PMD-200, including cables specified by the manufacturer. Otherwise, degradation of the performance of this equipment could result.

Essential Performance

All four signals (PPG, GSR, ACC, peripheral temperature) are considered as part of the system's essential performance, since they are all needed in order to calculate the index.

Technical Data

This table lists technical specifications and capabilities of the PMD-200 system.

Table 6: Technical Specifications

PMD-200 Monitor	
Parameter	Specification
System temperature range during transport or storage	From –10 C to 60 C
Relative humidity during transport or storage	30% – 70% non-condensing
Air pressure during operation and transport	70 kPa – 105 kPa in operating mode 50 kPa – 106 kPa in non-operating mode
Ambient operating temperature	From 10 C to 35 C
Relative humidity during operation	30% – 70% non-condensing
Liquid ingress	IPX1 Dripping Water Ingress Protection
Communication	1 USB port, 1 RS232 port
Standards	IEC 60601-1, IEC 60601-1-2, IEC 60601-1-6, ISO 10993, RoHS Directive
Power supply	100 VAC– 240 VAC, 700 mA, 50/60 Hz
Power consumption	Approximately 60 W
Mode of operation	Continuous

PMD-200 Monitor	
Parameter	Specification
Battery	• Cell Type: Li-Ion 3.7V, rechargeable • Basic cell Samsung ICR18650F • Battery capacity: 2.6Ah • Normal Voltage: 11.1V • Maximum charging time is 2 hours • Operating temperature: 0 to 45°C during charging and -20 to 60°C during discharging • Elevated temperature shut-off: 72°C
Dimensions	PMD-200 monitor: (H) 240 mm × (W) 193 mm × (D) 150 mm
Weight	PMD-200 monitor: approximately 3.5 kg Shipping weight: 5kg
User interface	Touchscreen and 1 button (ON/OFF)
Expected service life	5 years
Disposal	Dispose of according to local regulations

Finger Probe	
Parameter	**Specification**
Finger Probe temperature range during transportation or storage	From –10 °C to 60 °C
Ambient operating temperature	From 10 °C to 35 °C
Relative humidity during operation	30% – 70% non-condensing
Relative humidity during transport or storage	30% – 70% non-condensing
Air pressure during operation and transport	70 kPa – 105 kPa in operating mode 50 kPa – 106 kPa in non-operating mode
Dimensions	Finger Probe: 85 mm X 40 mm Finger Probe + Cable: 3000 mm
Weight	Finger probe: 0.090 Kg

Finger Probe	
Parameter	**Specification**
Disposal	Dispose of according to local regulations
PVC Free, LATEX Free, DEHP free, Biocompatible	

Single use Sensor	
Parameter	Specification
Product temperature range for transportation	From –10 °C to 50 °C
Ambient operating/storage temperature	From 10 °C to 35 °C
Disposal of used sensors	Dispose of as biohazard
PVC Free, LATEX Free, DEHP free, Biocompatible sensor	

10. Troubleshooting

General Troubleshooting

Table 7: General Troubleshooting

Problem	Suggested Action
The monitor is not powered ON when you press the Power button.	1. Check if the power cable is connected to the electrical socket. 2. Check if the Power switch on the back panel is switched to ON.
The signals are not displayed on the screen.	1. Check if the finger probe cable is connected correctly to the PMD-200. 2. Check if the finger probe and the single-use sensor are connected correctly to the patient. 3. Restart the monitor by turning it off and on again.
The buttons on the menu bar do not respond.	1. Use a soft stylus tip and aim to the center of the button. 2. Press the Power button on the monitor front to turn off the monitor, then turn it back on. 3. If the problem persists, contact your Medasense representative.
The signals are of poor quality or unstable.	1. Make sure the clinical setting is not the cause (pressure against patient's hand or arm, blood pressure cuff on same hand as the finger probe, etc.). 2. Make sure patient's condition is not the cause (hypovolemia, low perfusion, contraindication, etc.). 3. Make sure the finger probe cable is well connected to the PMD-200, and there is no electrical interference from other cables. 4. Make sure the finger probe is well positioned on patient's finger, that the pleth sensor is not aligned with a phalanx joint, and that the fingertip touches the nub of the probe. 5. Make sure there is a good contact between the finger probe and the single-use sensor. 6. After stages 1-5 wait 60 seconds to allow the signals to recover. 7. If problem persists, restart the monitor by turning it off and on again.

Alerts and Informational Signals

Alerts and informational signals are displayed in the status bar at the top of the screen if signal quality is inadequate or a power supply or hard drive problem occurs.

Note

	The system assesses signal quality and will not display a NOL value if the signal quality is inadequate.



Figure 63: Alerts and informational signals displayed on the information pane

Alerts: Marked in red, representing a higher priority indication that should be addressed before continuing to use the NOL index value.

Informational signals: Marked in orange or blue, representing lower priority indications for the user's attention.

Pressing the indicator will open an internal message window with additional information about the detected issue.

The possible alerts and informational signals and their meanings are listed in the following table.

Table 8: Alerts and informational signals

Alert/Informational signal	**Meaning**	**Internal message** Pressing the indicator will provide additional information
Pleth	The Pleth (photoplethysmograph) signal is inadequate. The following reasons could apply: 1. Poor hand positioning or any limitation to proper perfusion. 2. Extreme clinical conditions (such as hypovolemia) which interfere with adequate signal acquisition. 3. The patient finger is not located properly inside the Finger Probe. 4. The Finger Probe is faulty.	
Conductance	The Galvanic Skin Response signal is inadequate. The following reasons could apply: 1. The single-use sensor is not located properly or not adhering adequately on the patient's finger. 2. The single-use sensor is not connected properly to the Finger Probe. 3. The single-use sensor is faulty.	
Check Probe	The system detected a problem with the Finger Probe. The following reasons could apply: 1. The Finger Probe is not connected to the monitor 2. The Finger Probe or one of its sensors is faulty - contact a Medasense representative.	

Alert/Informational signal	Meaning	Internal message Pressing the indicator will provide additional information
Movement	The system detects movement	
Movement	The system detects that the patient is moved to Trendelenburg/Anti-Trendelenburg position. NOL is frozen for 30 seconds.	
Temperature	The system detects that skin temperature is above the validated range. Interpret NOL readings with care.	
Temperature	The system detects that the skin temperature is below the validated range. Interpret NOL readings with care.	
 	Power status: Connected to power outlet (green with plug icon) Battery operated with charge level indicator (red)	

If the system cannot calculate the NOL values for longer than 30 seconds, no index value is displayed in the NOL index value pane and the trend is interrupted. When the problem is solved, the NOL index and trend are displayed after a short recalibration period (the NOL pane will display the message “Recalibrating”).



Figure 64: NOL is not displayed due to low signal quality

On-screen notifications

During routine usage of the PMD-200 system, the following on-screen notifications may appear:

Finger Probe not connected

When the system identifies that the Finger Probe is not connected to the system, the following on-screen notification will appear after 1min

Figure 65: Finger Probe not connected on-screen notification

Working on battery mode

When the system identifies switching to battery mode, the following on-screen notification will appear



Figure 66: System is working on internal battery on-screen notification

The battery icons described in Table 8 will be red. When encountering this on-screen notification, please check the following:

1. System connection to power cable
2. Power switch is on (–)

RAM memory on-screen notification:



Figure 67: RAM memory on-screen notification

When encountering this on-screen notification, please restart the system. If the problem persists, please call a technician.

Low disk space

When the hard drive memory reaches 70% of its capacity the system will inform the user that the disk space is getting low.



Figure 68: Low disk space on-screen notification

When encountering this on-screen notification do the following:

1. Export data in order to preserve past recording sessions
2. Delete old recordings

If the user will not delete old recordings, the system will do so automatically, in order to enable new recordings. The following on-screen notification will appear:



Figure 69: Old recordings have been deleted on-screen notification

Synchronization Error

When the system is powered ON, the system tests synchronization between the monitor and the sensors. If the test fails, the **Synchronization failed** on-screen notification is displayed. In the status bar, the synchronization failure icon is also displayed.

Figure 70: Synchronization Failed on-screen notification and Icon

In this case, contact your Medasense representative to arrange a service visit for testing the system.

Firmware Error

If the system firmware does not perform properly, the **Internal error** on-screen notification is displayed.

Figure 71: Internal Error on-screen notification

In this case, contact your Medasense representative to arrange a service visit for testing the system.

Processing Error

If during a recording the system identifies a processing error, the **Something went wrong** on-screen notification is displayed.

Figure 72: Something Went Wrong on-screen notification

In this case, contact your Medasense representative to arrange a service visit for testing the system.

11. Connectivity with other systems

The PMD-200 offers connectivity with third-party systems in the hospital, such as multi parameter vital sign monitors in the operating room enabling the display and/or storage of NOL information.
This may require the installation of an optional connectivity kit (can be ordered through an official Medasense distributor) as well as set up of the third-party system by the relevant vendor.
When Connectivity with a third party system is required, please contact your Medasense representative to ensure optimal implementation.

Once connectivity is set up and installed, information from the PMD-200 will be displayed or saved on the third-party system, including information such as:

1) NOL trend (and values)
2) Pleth tracings
3) Alerts and informational signals

A small delay time (usually of a few seconds) is expected between the information being displayed on the PMD-200 and it appearing on the third-party system.

At the time of writing this document, connectivity solutions are offered for displaying NOL information on:
Select Philips Intellivue™ monitors (through the Intellibridge™ connectivity platform)

Select Mindray Benevision™ monitors (through the Benelink™ connectivity platform)

Note:

Philips, Intellivue and Intellibridge are registered trademarks of Koninklijke Philips N.V.

Mindray, Benevision and Benelink are registered trademarks of Shenzhen Mindray Bio-Medical Electronics Co., Ltd.

Additional information is available from Medasense representatives.

Please contact your Medasense representative for up-to-date information about connectivity options.

12. Limited Warranty

1. Medasense Biometrics Ltd. ("Medasense") warrants that the PMD-200 monitor ("Warranted Product") will be free from material defects in workmanship or materials, when given normal, proper, and intended usage for a period of (i) fifteen (15) months from delivery, or (ii) twelve (12) months from installation, the shorter of the two periods or such other term as is required by applicable law to the extent longer then both periods ("Warranty Period"). Notwithstanding the above, the Warranty Period for the PMD-200 finger probe shall be three (3) months from installation.

2. Medasense' sole obligations under this warranty are to repair or replace any Warranted Product (or part thereof) that is determined by Medasense to be covered by this warranty and to be materially defective in workmanship or materials provided that the Distributor has given written notice of such warranty claim within the Warranty Period and shipped the Warranted Product back to Medasense' factory or such other place designated in writing by Medasense with freight prepaid. All Products or parts replaced shall become Medasense' property. Repair or replacement of Warranted Products under this warranty does not extend the Warranty Period.

3. Following receipt of a Warranted Product, if Medasense reasonably determines that a repair or replacement is covered by the warranty, Medasense shall reimburse the costs of shipping the repaired or replacement Warranted Product to the Distributor. Risk of loss or damage during shipments under this warranty shall be borne by the party who pays for the shipping of the Warranted Product. Warranted Products shipped by Distributor under this warranty shall be packaged in the original shipping container or equivalent packaging to protect the Warranted Product. If Distributor ships a Warranted Product in unsuitable packaging, any physical damage present in the Warranted Product on receipt by Medasense (and not previously reported) will be presumed to have occurred in transit and will be the responsibility of Distributor.

4. This warranty does not extend to any expendable components, single uses and/or supply items such as, but not limited to, electrodes, cables and/or Warranted Products or part thereof that have been: (i) subject to misuse, neglect, or accident; (ii) damaged or are non-conforming by causes external to the Warranted Product, including but not limited to failure of or faulty electrical power; (iii) stored, installed, operated, used or maintained in violation of Medasense' instructions or specifications; (iv) employed or affixed with attachments, features or devices that are

not supplied by Medasense for such use or are not approved in writing and in advance by Medasense for such use, or improper matching of Warranted Product components; (v) modified, disassembled, serviced, repaired or reassembled by anyone other than Medasense, unless authorized by Medasense. Medasense shall have no obligation to make repairs, replacements, or corrections which result, in whole or in part, from normal wear and tear. Medasense makes no warranty (a) with respect to any products that are not Warranted Products, (b) with respect to any products purchased from a person other than Medasense or its official distributor or (c) with respect to any product sold under a brand name other than Medasense.

5. ALL PRODUCTS ARE SUPPLIED “AS IS”. THIS WARRANTY IS THE SOLE AND EXCLUSIVE WARRANTY FOR MEDASENSE PRODUCTS, EXTENDS ONLY TO THE DISTRIBUTOR, AND IS EXPRESSLY IN LIEU OF ANY OTHER EXPRESS OR IMPLIED WARRANTIES INCLUDING WITHOUT LIMITATION ANY WARRANTY AS TO MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

6. Medasense does not warrant nor make any representation regarding the results of its customer's and/or its distributors' and/or any third party's use or omission to use the respective Warranted Product and/or any information or data provided by the respective Warranted Product in terms of inter alia correctness, accuracy, completeness, reliability or otherwise.

7. THE REPAIR AND/OR REPLACEMENT OF WARRANTED PRODUCTS (AND/OR ANY COMPONENTS THEREOF) IN THE MANNER PROVIDED ABOVE WILL CONSTITUTE FULL AND FINAL FULFILLMENT OF ALL OF MEDASENSES’ OBLIGATIONS WITH RESPECT THERETO.

8. The effectiveness of this warranty with respect to each Warranted Product shall be subject to and contingent upon the full payment of the consideration due for such Warranted Product by the Distributor to Medasense.